4-113-060-**11**(1)
4113060111

SONY

KDL-40WL140
KDL-46WL140
KDL-52WL140

Quick Setup Guide

For further information, see the Operating Instructions Manual supplied with the TV. Please retain this guide for your future reference. Assembly may be required on some models.

For Your Convenience

Please contact Sony Customer Support directly if you have questions on the use of your television after reading your Quick Setup Guide and Operating Instructions Manual.

For United States

http://www.sony.com/tvsupport

or to speak with a support representative:
1-800-222-SONY (7669)

For Canada

http://www.sony.ca/support

or to speak with a support representative:
1-877-899-SONY (7669)

Please Do Not Return the Product to the Store

FSC
Mixed Sources
Product group from well-managed forests, controlled sources and recycled wood or fiber
Cert no. SCS-COC-001395
www.fsc.org
© 1996 Forest Stewardship Council

©2008 Sony Corporation Printed in U.S.A.

Connecting Your New BRAVIA® LCD HDTV

Congratulations! Your new BRAVIA® TV opens the door to a "Full HD Experience". This guide will explain how to get the most from your new High-Definition TV.

Please take these steps before you power up your **BRAVIA**:

- Register online at:
  http://www.sony.com/registration (from U.S.A.)
  http://www.sonystyle.ca/registration (from Canada)
- Make sure you've removed all accessory contents from packaging.
- Install 2 AA batteries (supplied separately) in your remote control.
- Determine whether you will mount your TV on a wall or place it on a floor stand. Sony wall-mounting brackets are designed to provide the best fit.
- Give your TV 2 3/8 inches (6 cm) of space behind it to properly ventilate.

The Four Steps to a Full HD Experience: Set, Sound, Source, and Setup

Along with your **BRAVIA** TV **set**, a complete HD system requires an HD **sound** system, a **source** of HD content, and proper **setup** connection with components such as your HD cable or satellite box.
You must get HD programming to experience the stunning detail of HDTV.

The quality of the image you see on your **BRAVIA** can only be as high as the quality of the signal it is displaying. This chart shows the different signal types and how to access them.

Best Signal Performance ↑

	Comments	Sources
High Definition Content	Best Picture Quality 16:9 Aspect Ratio	HD Over-The-Air Antenna HD Cable Subscription/ Programming HD Satellite Subscription
Digital Content	Good Picture Quality Aspect Ratio based on Program	Over-The-Air Antenna Digital Cable Subscription Digital Satellite Subscription
Analog Content	Original TV format 4:3 Aspect Ratio	Over-The-Air Antenna Cable Subscription

Contact your cable or satellite provider to upgrade your service to HD. Receive over-the-air HD broadcasts with an HD-quality antenna (www.antennaweb.org) and discover the wealth of entertainment now available on super-high-resolution Blu-ray Disc™.

Your **BRAVIA** TV must be properly connected to components such as sound system and cable or satellite box.

See reverse side of this guide for sample connection diagrams.

- Turn off and unplug all components before making connections.
- Do not turn on the TV until connection setup is completed.

Audio/Video Performance ↑

Input Connector	Video Connection	Audio Connection	High or Standard Definition Quality
HDMI 1 **HDMI 2** **HDMI 3** **HDMI 4**	HD **HDMI connection***	HDMI cable carries both video and audio signals. (*When HDMI is connected to DVI with an adapter, a separate audio L/R is necessary.)	1080/24p, 1080p, 1080i, 720p, 480p, 480i, PC (Compatible with HD or SD content)
Component 1 **Component 2**	HD **Component connection**	**Audio L/R**	1080p, 1080i, 720p, 480p, 480i (Compatible with HD or SD content)
Video 1	**S VIDEO connection** (Use this connector in place of composite video connector)	**Audio L/R**	480i (SD content)
Video 1 **Video 2** **Video 3**	**Composite video connection**	**Audio L/R**	

What is HDMI™?

HDMI (High-Definition Multimedia Interface) cables are the standard for connecting HDTV. They are built to properly handle high bandwidth, uncompressed video and multi-channel audio—all in one cable.

Connecting a PC to Your BRAVIA

- May require **DVI-to-HDMI** adapter and separate audio connector.
- Connect PC's audio output when using a Digital Video Interface (DVI) or HD15 connection.
- Press PC's FUNCTION Key + Select Output to transmit to TV.
- When using an HD15 connection, adjust TV's **Pitch** and **Phase** to correct sharpness.
- Refer to your **BRAVIA** Operating Instructions Manual for more information.

To learn more about HDTV, visit:
U.S.A.: http://www.sony.com/HDTV
Canada: http://www.sonystyle.ca/hd

Running Initial Setup

Run the **Initial Setup** to scan for the available analog and digital channels after connecting your signal source to the CABLE/ANTENNA input on the rear of the TV.

1 The **Initial Setup** screen will appear when your **BRAVIA** is powered on for the first time. Select the language for the OSD (on screen display) from the screen shown below.


Initial Setup
Step 1 of 6
Please select a language. Language settings will apply to on screen display as well as default audio for digital channels. Highlight a choice and press to continue.
English
Español
Français

2 Follow the instruction provided on the screen.
Note: If you are using a cable or satellite box, select the **Skip** option to skip the **Auto Program**.

3 When all receivable channels are found, press ➡ to continue to set the current time.

4 Continue on to set up the TV Guide On Screen™ if you are not using a cable or satellite box. Follow the on-screen instruction to set up your system.

TV GUIDE REMINDER!
TV Guide On Screen interactive program guide
Built-in to this Sony TV!
▸ 24 hours of listings
▸ Powerful show searches
▸ Subscription free
Highlight an option and press SELECT on your remote.
Start setup
Remind me to set up later
Don't remind me again

Note: Your TV will need to be left powered off (overnight) to receive TV Guide data.

When your program information is obtained, your TV will display the program listing. (See Operating Instructions Manual for more details.)

Watching Your TV

Remote Control and XMB™

Press **HOME** to display the **XMB**™ (XrossMediaBar).

XMB™ (XrossMediaBar) with focus on **Settings**. Select **Settings** to customize your TV.

XMB™ (XrossMediaBar) with focus on **TV** icon. Select the channels from here or use the **0-9** number buttons on your remote control.

XMB™ (XrossMediaBar) with focus on **External Inputs**. Select connected device from here or use the **INPUT** button on your remote control.

Input: Select Your Content Source

Whether you are watching cable, satellite or broadcast TV; playing a VCR, DVD or Blu-ray Disc; or connecting to your PC, you need to choose the correct input using your remote control:

- Press **HOME** on your remote control to display the **TV** or **External Inputs** selection list; OR
- Press **INPUT** to display the input selection menu as shown below. You can use both **INPUT** or ↑/↓ to toggle through the list.



The TV will automatically detect the connected equipment. Shown here with equipment connected to Video 1, Component 1 and HDMI 1.



Inputs can be managed by labeling them with the name of the connected equipment as shown here. See the Operating Instructions Manual for details.

Customize Sound and Picture Quality

You can choose optimum sound and picture settings to match the content you are displaying on your TV:

- Press **HOME** on your remote control to display the **XMB**™ and select **Picture** or **Sound** from the **Settings** menu. Choose the appropriate setting for your content.
- Use the **OPTIONS** button to quickly access **Picture Adjustments** and **Sound Adjustments**.
- Refer to your Operating Instructions Manual for more information.

Adjust Screen Shape and Aspect Ratio

High-Definition and Standard-Definition signals are transmitted with different aspect ratios (the width-to-height shape of the image). Most HD signals use a widescreen aspect ratio of 16:9. Most SD signals use a boxy 4:3 aspect ratio. The 16:9 aspect ratio looks perfect on your **BRAVIA**, but a 4:3 image may need to be adjusted to better fill the wide screen of your **BRAVIA**.

- Adjust your TV so boxy 4:3 images are automatically re-configured (zoomed or stretched) to fit the wide TV screen; OR
- Watch SD content in its original, boxy format with wide black bars surrounding the image to fill in unused space (for example, you may prefer to watch an old classic movie in its original 4:3 format, not reconfigured for a wide screen).
- Press **WIDE** on your remote control. Your TV will display available wide modes for the current signal. Select the **Wide Mode** setting of your preference.

To Do List

When the **Initial Setup** is completed, consider carrying out these items:

Set Closed Captions (CC)
Set Parental Lock
Show/Hide Channels
Manage Inputs (Label/Enable Inputs)
Set Speakers

For details, refer to your **BRAVIA** Operating Instructions Manual.

Favorites

Use the **Favorites** feature to manage your favorite channels and inputs for easy access.



- Press **FAVORITES** to access **Favorites**.
- In **Favorites**, you will see a list of your most recently viewed channels and external inputs. Highlight a channel or external input and press ⊕ to tune to it.
- To add a channel or external input to your **Favorites** list, tune to it and press **OPTIONS**, then select **Add to Favorites**.
- See the Operating Instructions Manual for more details on this feature.

HD Basic Connection with A/V Receiver



HD BRAVIA Sync Basic Connection



* Signifies a BRAVIA Sync capable device.

HD Basic Connection with Home Theater System



Required Cable Types for Connection



Notes on Connection:

- Your TV is equipped with four HDMI inputs. Connect your incoming signal source (HD Cable Box, HD Satellite Receiver, or DVD) with HDMI or component video for the best possible picture quality.
- If your connecting equipment has DVI output instead of the HDMI output, you must use a DVI-to-HDMI cable for the video and also connect an audio cable for the sound. If this is the case, connect the cable to HDMI IN 4 (input) of your TV.
- **P&P/PIP** functions require Cable/Antenna connection.
- When receiving a high-definition signal by an over-the-air antenna, it is best to use an HD antenna.
- When using a DVI-to-HDMI cable, make sure to connect the DVI side first.

Basic Connection with SD VCR/DVD



Notebook PC Connection



Desktop PC Connection